

EFET™ 535

Installation Manual

Warning!
*This manual is only to be used by a
professional installer to install and
set up the thermostat properly.
It is not intended for the end-user!*

Congratulations with...

... your Danfoss floor heating system

Your property has been installed with a Danfoss electric floor heating system. Danfoss is Europe's leading floor heating manufacturer, with over 45 years experience. We are confident that you will be satisfied with your new system.

Danfoss brings you...

An Invisible heating solution - A concealed heat source opens up greater opportunities for decorating and furnishing.

Optimum comfort - Danfoss brings you the luxury and comfort of a warm floor as well as a pleasant room temperature. Floor heating is the most comfortable type of heating because it is based on the fact that warmth travels upwards; pleasant warmth for your feet, body and head.

Low running costs - Thanks to the precise Danfoss thermostat and the placement of the heating elements right under the floor surface the heat can be controlled optimally in order for you to have the comfort you desire with minimal energy use. Moreover electric floor heating is practically maintenance free, in total keeping down the running costs.

A long lasting solution - We back-up our floor heating solutions with a ten year guarantee on all our mats and cables, and a two year warranty on our thermostats. Practically speaking you can count on Danfoss heating cables and mats lasting as long as the house in which they are installed - and that is without having to maintain them.


Hygiene - As Danfoss produce floor heating systems, only very gentle air is circulating, and the amount of travelling dust particles is reduced considerably; a great relief for people with allergies or asthma. There are also no dangerous fumes such as carbon monoxide generated by the system.

Table of content

Install & configure the thermostat	4
Placement of EFET™ 535	4
Installation of EFET™ 535	5
User's guide to EFET™ 535	10
Introduction	10
Display, icons and buttons	10
Increase / decrease preferred temperature.....	11
Using the timer function	12
Settings	14
Setting the time	16
Setting the weekday.....	17
Setting the timer periods	18
Setting the comfort temperature	19
Setting the savings temperature	19
Setting the minimum floor temperature limit. .	19
Special features.....	20
Childproof mode	20
Frost protection mode.....	20
OFF mode.....	21
Restore timer default settings.....	21
Switching displayed temperature	22
Trouble shooting	23
Technical Specifications	24
Disposal Instruction.....	25
The Danfoss Guarantee	26

Install & configure the thermostat

Placement of EFET™ 535




When EFET™ 535 is used as a room sensor, installation height should typically be between 80-150 cm.



In wet rooms it should be installed on an even surface, according to local building regulations.



At least 50 cm away from windows/doors that will be left open occasionally.



Not on a wall where it will be subjected to direct sunlight.




Not on the inner side of a wall facing the outside.

Installation and connection


Installation of EFET™ 535

1. To remove the front cover, gently press the release tabs under the bottom of the thermostat with a screwdriver. Then remove the front.



Removing the front cover and pushing the installation button, is not intended to be done by anyone else but a qualified installer!

2. Connect the thermostat according to the connection diagram



The screen of the heating cable must be connected via a terminal strip to the earth wire of the supply cable.

Choose sensor combination

3. Choose sensor combination

When installing the EFET™ 535 you need to choose the type of heating and thus which sensors should be used. You have three options:

Comfort heating: Constant temperature on the floor in bathrooms and other rooms where a comfortable warm surface is required.

Install the Floor sensor and choose only the Floor sensor.

Total heating: Control of room temperature in living rooms etc. Install the Floor sensor and choose both Floor sensor and Room sensor.


No floor sensor: A floor sensor is not present, and cannot be installed. Choose Room sensor. (Not recommended).

Be aware that without a floor sensor, the temperature control can be less accurate, and overheating of the floor is of higher risk.

Danfoss recommends that a floor sensor is always installed.

When the thermostat is used to control a floor heating element according to EN/IEC 60335-1 and EN/IEC 60335-2-96, always use the floor sensor and never set the temperature limit above 35°C.

Configuration - sensor



Selection of sensor type
Power on the thermostat.




With the front off, with a small screwdriver, pencil, or needle press the installation button.

Select the sensors to be used for the heating system:

EFET™ 535 is able to use two sensors:

- a built-in room sensor
- an external sensor to be placed in the floor.

This gives 3 options:

-  floor sensor.
-  room sensor.
-  both room and floor sensor.

Always use floor sensor or a room + floor sensor combination when used to control floor heating


The default is 



To change this setting, press ● and use the arrow buttons ▲▼ to select your choice. Press ● to accept your choice.

If you have selected room sensor only, the installation procedure is complete. Press installation button to accept. (Go to page 9).


If you have selected floor sensor or a combination of room- and floor sensor press ▲▼ for the next setting.

Configuration - Max. floor temp.



Maximum floor temperature.
When selecting either  floor sensor or  floor and room sensors, next screen is maximum floor temperature.

Default setting is 35°C.



To change this setting, press ● and use the arrow buttons ▲▼ to select your choice. Press ● to accept your choice.

If you have selected a combination of room and floor sensor, the installation procedure is complete.

Press installation button to accept.
(Go to page 9)

If you have selected floor sensor only press ▲▼ for the next setting.


When the thermostat is used to control a floor heating element according to EN/IEC 60335-1 and EN/IEC 60335-2-96, always use the floor sensor and never set the temperature limit above 35°C.

Notice:


The floor temperature is measured where the sensor is placed. The temperature of the bottom of a wooden floor can be up to 10 degrees higher than the top. Floor manufactures often specify the max. temperature on the top surface of the floor.

Please contact your floor supplier for maximum surface temperature.

Configuration - Scale







Scale


If you select EFET™ 535 to only use a floor sensor, mode , you have to select the display type. The choice is either numerical scale 1-6 or Celcius scale 5° to 45°.



INT


Default is Celcius scale. When selecting Celcius, the display will show the actual temperature at the floor sensor.



To change this setting, press  and use the arrow buttons   to select your choice.

Press  to accept your choice. The installation procedure is now finished.

You can use the   for going back or forward through the settings.



Otherwise:
Press the installation pinhole to exit installation mode.

4. Put the frame and front back on.

Initially mains supply the thermostat for 15 hours to fully charge the battery. The current time and day is then kept for 80 days if mains supply is off. All other settings are stored permanently.

User's guide to EFET™ 535

EFET™ 535 Introduction

EFET™ 535 is an electronic timer temperature controller, specially designed for floor heating systems.

The EFET™ 535, once set, automatically adjusts the heating to meet your comfort levels, regardless of changing weather conditions by measuring the floor temperature and combining it with the air temperature.

Even the programming of economy temperatures (i.e. lowering of temperature during the night and when you are out of the house) is very simple. Just tell the EFET™ 535 your daily rhythm and choose your program.

It also features a minimum floor temp. setting, eg. for keeping your tile floors warm in summer as well.

Display, icons and buttons



This is a safety switch, meaning all electrical supply to the thermostat is disconnected when turned off.

This is the standard display. The currently measured temperature is shown.

⬆ is shown to symbolize that current temperature is displayed, i.e. unit working as a thermometer.

The thermostat is operated with the 3 buttons below the display.


- ▼ down
- ▲ up
- select

Two pinhole buttons are available for dedicated features

- 🔒 Childproof. Locks all buttons.
- 🕒 Settings.

Increase / decrease temperature

The display indicates:



INT

Increase / decrease preferred temperature.



Use the arrow buttons \blacktriangle \blacktriangledown to either increase or decrease the temperature. The temperature is changed in increments of 0.1°C .

Notice that the temperature is flashing. Whenever something is flashing you are making changes.

When the preferred temperature is found you can save the setting in two ways


- Press \bullet to accept
- Leaving it flashing for 10 seconds.

If you try to increase the set point above the max. floor limit (p. 8) when thermostat is operating only on floor temperature, this icon will flash \blacktriangle

Timer function


Using the timer function

The thermostat has a built-in timer function. A status bar in the bottom of the display gives an overview of timer status.





The day is divided into 4 time periods analogous to the typical day programming pattern:

- Morning
- Day
- Evening
- Night



These are indicated by the  as shown in the picture to the left. The start time of each of these can be configured.

The symbol can be:

-  Empty: Indicating that the thermostat is in economy mode.
-  Full: Indicating that the thermostat is in comfort mode.

The 4 programs

4 different programs can be selected

Program 1	Manual mode. The temperature is maintained constantly 24 hours all week.
Program 2 	<p>The temperature is lowered to economy temperature during the day and night period all week.</p> <p>P2 is a day program for e.g. working days where the temperature is decreased during the middle of the day and at night. In the morning and evening comfort temperature is preferred.</p>
Program 3 	<p>The temperature is lowered to economy temperature during the night period all week.</p> <p>P3 is a program for days at home where comfort temperature is preferred during the day and a savings temperature at night.</p>
Program 4	<p>A week program where: Mon – Fri: Program 2 and Sat – Sun: Program 3</p> <p>P4 is a week program with Monday-Friday as workdays and Saturday-Sunday as days off. The top 7 bars indicate Monday through Sunday. On week days timer program 2 is used and in weekends timer program 3.</p>

INT

Factory setting is Program 1. Manual mode.


Factory settings

The factory setting of the timer is:

	Floor sensor only	Room sensor only	Floor and Room sensor
Temperature:			
Comfort	25°C	21°C	21°C
Economy	5°C	17°C	17°C
Periods – Day rhythm:			
Morning	06:00-08:00		
Day	08:00-16:00		
Evening	16:00-22:30		
Night	22:30-06:00		


You can use the above as it is, or you can change the settings to match your day pattern. See the chapter Settings – setting the timer periods, page 18.

Changing timer program




To change the program:
(Remember, you need to set the time in advance, p.17)

Keep the ● button pressed for 2 seconds.
The actual program starts to flash.
It is now possible to change the program by using the buttons ▲▼
Press ● to accept





Changing timer program





During the timer programs, P2, P3, and P4, the flashing  indicates the actual time period.

In program 4 the actual day is also shown.


Using the arrow buttons   in timer mode, is somewhat different from manual mode.

INT



If you increase/decrease the temperature in a savings period  this change only applies to this current period, not any future savings periods. You might use this if you are eg. working at home in timer program 4.



If you increase/decrease the temperature in a comfort period  this change applies to all future comfort periods, until changed again. From the perspective that you are fine tuning the comfort temperature.

Settings overview

Settings

All settings are under ⌚ the settings menu. Here you set the following:



- Time



- Weekday



- Timer periods configuration
(Morning, day, evening and night)



- Comfort temperature




- Savings temperature



- Min. floor temperature limit
(Only when combination of room
and floor sensor is installed).

Changing the settings




You enter the settings by pressing the ⌚ pinhole with a small screw driver, pencil, or needle, the display now changes from temperature to time display.

By using the arrow buttons ▲▼ you move one way or the other in the menu.

INT

Setting the time



By pressing the ● the hours start flashing, indicating you can change them with the arrow buttons ▲▼

Press the ● again to change the minutes.

Battery Backup: The current time and day is kept for 80 days if mains supply is off. All other settings are stored permanently. Initially mains supply the thermostat for 15 hours to fully charge the battery.




Setting the weekday

By pressing the ● the weekday starts flashing, indicating you can change it with the arrow buttons ▲▼ Press the ● to accept

Changing the settings

Setting the timer periods

When programming the starting times of the 4 periods keep in mind that the thermostat will start heating/stop heating at the given time. Therefore some periods should start and end before, to compensate for the time it takes to heat up or down.


The first period bar  flashes indicating this is the morning period.



By pressing the ● the start time of the period starts flashing. You change it with the arrow buttons ▲▼ in increments of 15 minutes.


Press the ● to accept



The second period bar  flashes indicating this is the day period.


Setting it in the same way.



The third period bar  flashes indicating this is the evening period.

Setting it in the same way.



The fourth period bar  flashes indicating this is the night period.

Setting it in the same way.

Note! When setting the time periods you cannot step backward to the previous time period, until the last one is set. This is to ensure that the periods do not overlap.

Changing the settings



Setting the comfort temperature

By pressing the ● the preset comfort temperature starts flashing.

You change it with the arrow buttons ▲▼

Press the ● to accept

INT



Setting the savings temperature

By pressing the ● the preset savings temperature starts flashing. You change it with the arrow buttons ▲▼

Press the ● to accept
It can also be set to OFF.



Setting the minimum floor temperature limit

If the thermostat is installed as a combination of room and floor sensor the minimum comfort temperature on the floor can be selected.

Setting this will overrule any other set point as you always want e.g. 20°C at the floor sensor


--.° means that the function is disabled.

By pressing the ● the preset minimum floor limit temperature starts flashing.


You change it with the arrow ▲▼

Press the ● to accept

Special features



Childproof mode

You disable all buttons in child proof mode by pressing the pinhole button below  with a small screw driver, pencil, or needle.

A lock now appears in the display and all other buttons are locked now.

To unlock press the lock symbol again



Frost protection mode

To set the thermostat in frost protection mode, you hold down ▼ until you reach the lowest setting. Now press ▼ again to verify that you are not just changing the comfort or economy temperature, depending on the mode or timer period the thermostat is in.



The frost icon now appears and 5.0° flashes.

You accept the mode by

- Press ● to accept
- Leaving it flashing for 10 seconds.



The thermostat is now in frost protected mode. Actual temperature is shown.

You leave frost protection mode by pressing ▲ (0.5sec).

Special features



OFF mode

To set the thermostat in OFF mode, you hold down ▼ until you reach 5.0°. Now press ▼ again twice to verify that you are not just changing the comfort or economy temperature, depending on the mode or timer period the thermostat is in.

INT

The display now shows OFF.


You accept the mode by

- Press ● to accept
- Leaving it flashing for 10 seconds.

OFF mode is used if you want to shut off the thermostat for a long period, but still keeping the time setting.



The thermostat is now in OFF mode. Two lines are shown in the display. You leave OFF mode by pressing ▲ (0.5sec).



Restore timer default settings

To reset the thermostat to its timer defaults as shown on page 14, do the following:


1. Turn off the thermostat
2. While pressing the ⌚ pinhole button, turn on the thermostat. The LED will now flash red/green for 1 second indicating the thermostat will reset.

Special features / Trouble shooting




Switching displayed temperature

Depending on what mode the thermostat is installed as (floor, or a combination of floor and room) you can change which temperature is displayed.

If installed as a floor sensor system only, you can change the displayed temperature from floor sensor temperature to room sensor temperature, if you wish to use the thermostat as a thermometer. You change the display by pressing ▲ and ▼ at the same time for 2 seconds. The room sensor icon  is displayed.

You press them again to return to the default display.



If installed as a combination thermostat, by pressing ▲ and ▼ at the same time for 2 seconds, the temperature in the floor sensor is displayed for 2 minutes. The floor sensor icon  is displayed.

Trouble shooting



Clock symbol flashing:

Time settings were lost due to power cut.

The thermostat resumes to manual mode.

Trouble shooting

E 4

E4 flashing in display:

Error code 4 – The thermostat has overheated and has switched off

Let the thermostat cool for period. Then switch the thermostat off and on.

E 5

E5 or E6 flashing in display:

Error code 5 - Floor sensor short circuited

Error code 6 - Floor sensor disconnected.

E 6

Check connections, if they are OK, then disconnect the 2 sensor wires and connect an ohm meter to sensor wires.

Measure the ohm value and check with the values in the table in Technical Specifications below.

INT

Light Indications (LED)

The EFET™ 535 has a LED above the 2 pole safety switch.

The LED has five indications:

No light	The system is turned off.
Green light	System is standing by, set point temperature reached
Green light flashing	Floor sensor is defect
Red light	System is heating
Switching between red and green light	The floor temperature limit prevents the set point room temperature from being reached.

Technical specifications

Operation voltage	180-250 VAC, 50/60 Hz
Standby power consumption	Max. 0.30 W
Relay: • Resistive load • Inductive load	230V ~ 15A / 3450W $\cos \varphi = 0.3$ Max. 4A
Sensing unit	NTC 15 kOhm at 25°C
Sensing values: • 0°C • 20°C • 50°C	42 kOhm 18 kOhm 6 kOhm
Hysteresis	$\pm 0.2^{\circ}\text{C}$ with room sensor, $\pm 0.4^{\circ}\text{C}$ with floor sensor only
Ambient temperature	-10° to +30°C
Frost protection	5°C
Temperature range	5-35°C with room sensor, 5-45°C with floor sensor only. When used together with electrical floor heating elements, according to EN/IEC 60335-2-96 never adjust floor temperature above 35°C. Floor max. 20-50°C. Floor min. 10-35°C only when installed with room and floor sensor combination
Sensor failure monitoring	The thermostat has a built-in monitoring circuit, which will switch off the heating if the sensor is disconnected or short-circuited
IP class	31
Dimensions	85 mm x 85 mm

Disposal Instruction

All electric or electronic equipment and enclosed batteries containing materials, components and substances that can be harmful to people's healthiness and to the environment, if the waste is not handled correctly.

All electric or electronic equipment and batteries is marked with the below crossed sign of a dustbin or garbage can. This sign symbolize electric or electronic equipment and batteries which are not allowed to be removed or disposed together with the unsorted waste, but have to be gathered individually.

Some batteries are also marked with a chemical symbol Hg (mercury), Cd (cadmium) or Pb (lead). These are very harmful substances and for this reason it is very important to collect these batteries.

As end user it is important for you to hand in your used batteries for recycling. In this way you actively take part to ensure that the batteries are reused according to the law and do not unnecessary impact on the environment.

All countries have established collecting points or other collecting arrangements, where citizens free of charge can deliver scraped electrical and electronic equipment together with batteries for recycling. More information can be obtained at your local authorities.



The 2 Year Danfoss Warranty:

You have purchased a Danfoss heating system which we are sure will serve to improve the comfort and economy of your application.

Danfoss provides superior electrical heating solutions for total climate control in and around homes and buildings. Danfoss offers a complete product program with ECFLEX heating cable or ECMAT heating mat, ECTEMP thermostats and Danfoss selflimiting heating cable combined with additional products completing the product program.

This 2 year warranty applies to all Danfoss products.

Should you, against all expectations, experience a problem with your Danfoss product, you will find that Danfoss offers a 2 year warranty from the date of purchase on the following conditions:

During the warranty period Danfoss shall offer a new comparable product or repair the product in case the product is found to be faulty by reason of defective design, materials or workmanship. Repair or replacement shall be carried out at Danfoss's discretion. Danfoss shall not be liable for any consequential or incidental damages including, but not limited to, damages to property or extra utility expenses. This warranty shall only be valid on production of proof of purchase and must be submitted to the installer or seller without undue delay.

An extension of the warranty period following repairs undertaken under warranty cannot be granted.

The Danfoss Warranty shall not cover any damage caused by incorrect conditions of use, incorrect installation or if installation has been carried out by non-authorised electricians. All work will be invoiced in full if Danfoss is required to inspect or repair faults that have arisen as a result of any of the above.

The Danfoss Warranty shall not extend to equipment which has not been paid in full.

Danfoss will, at all times, provide a rapid and effective response to all complaints and inquiries from our customers.

The warranty explicitly excludes all claims exceeding the above conditions.

2 YEAR WARRANTY

Warranty Certificate

The Danfoss Guarantee is granted to:

Name:

Address:

City:

Country:

Telephone:

INT

Attention:

The Warranty Certificate must be completed correctly for the Warranty to be valid.
Please read the Warranty conditions on the previous page.

Type of thermostat:

Material number:

Electrical installation by:


Date:

Suppliers Stamp
Date / -



Article No.: 088L4374

Version - 01.01



Danfoss A/S
Ulvehavevej 61
DK-7100 Vejle
Tel: +45 74 88 85 00
Fax: +45 74 88 85 01
www.danfoss.com

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without consequential changes being necessary in specifications already agreed.
All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.